

plastic sheet or into a pan and divide the subsample into quarters. Use a random number generator or random number table to select one of these quarters.

(b) *Reduction of the particle size by the use of a 9.5 mm screen.* Collect the contents of the selected quarter of waste resulting from conducting the procedures in paragraph (a) of this section and shake the waste in a 9.5 mm screen. Separate the waste material which passes through the screen from the waste material which does not pass through the screen. Manually cut or otherwise reduce the size of all parts of the waste portion which did not pass through the 9.5 mm screen, such that each part of the waste shall pass through the 9.5 mm screen by shaking.

(c) *Drying the reduced particle size waste.* Dry all of the waste portion resulting from conducting the procedures in paragraph (b) of this section, from 10 to 15 hours in a drying oven at 100 °C. Allow the dried waste to cool to room temperature.

(d) *Mixing the dried waste.* Place all of the waste resulting from conducting the procedures in paragraph (c) of this section in a 19-liter pail or similarly sized, cylinder-shaped container. Mix the dried material according to one of the two following options:

(1) *First mixing option.* Completely close the container and roll the container a minimum of 10 complete revolutions to mix the contents.

(2) *Second mixing option.* Use a sturdy stirring rod, such as a broom handle or other device that reaches the bottom of the container, to stir the waste for a minimum of 10 complete revolutions around the container at a distance approximately half way between the outside and the center of the container.

**§ 761.355 Third level of sample selection.**

The third level of sample selection further reduces the size of the subsample to 100 grams which is suitable for the chemical extraction and analysis procedure.

(a) Divide the subsample resulting from conducting the procedures in § 761.353 of this part into 100 gram portions.

(b) Use a random number generator or random number table to select one 100 gram size portion as a sample for a procedure used to simulate leachate generation.

(c) Dry the 100 gram sample, selected after conducting the procedure in paragraph (b) of this section, for 10 to 15 hours in a drying oven at 100 °C and cool it to the analytical laboratory room temperature before analysis using a procedure used to simulate leachate generation. This sample was dried previously in the larger quantity sample at the second level of sampling (§ 761.353(c)) and is dried a second time here (in the third level of sample selection). This dried and cooled sample must weigh at least 50 grams.

(d) If the dried and cooled sample weighs <50 grams, select additional 100 gram portions of sample one at a time by repeating the directions in paragraph (b) and (c) of this section, and add each additional 100 gram portion of sample to the first 100 gram portion until at least 50 grams of dried material is in the sample to be analyzed using a procedure used to simulate leachate generation.

**§ 761.356 Conducting a leach test.**

No method is specified as a procedure used to simulate leachate generation.

**§ 761.357 Reporting the results of the procedure used to simulate leachate generation.**

Report the results of the procedure used to simulate leachate generation as micrograms PCBs per liter of extract from a 100 gram sample of dry bulk product waste. Divide 100 grams by the grams in the sample and multiply this quotient by the number of micrograms PCBs per liter of extract to obtain the equivalent measurement from a 100 gram sample.

**§ 761.358 Determining the PCB concentration of samples of waste.**

Use either Method 3500B/3540C or Method 3500B/3550B from EPA's SW-846, Test Methods for Evaluating Solid Waste, or a method validated under subpart Q of this part, for chemical extraction of PCBs from individual and composite samples of PCB bulk product waste. Use Method 8082 from SW-

## Environmental Protection Agency

## § 761.375

846, or a method validated under subpart Q of this part, to analyze these extracts for PCBs.

### § 761.359 Reporting the PCB concentrations in samples.

Report all sample concentrations as ppm by weight on a dry weight basis.

### Subpart S—Double Wash/Rinse Method for Decontaminating Non-Porous Surfaces

SOURCE: 63 FR 35472, June 29, 1998, unless otherwise noted.

#### § 761.360 Background.

The double wash/rinse procedure is used to quickly and effectively remove PCBs on surfaces. It is important to select and use the proper cleanup equipment, to conduct the procedure correctly so as not to redistribute PCBs, and to comply with disposal requirements for all cleanup materials.

#### § 761.363 Applicability.

The double wash/rinse procedure includes two washing steps and two rinsing steps. The two washing and rinsing steps are slightly different depending on whether a contaminated surface was relatively clean before the spill (see § 761.372), or whether the surface was coated or covered with dust, dirt, grime, grease or another absorbent material (see § 761.375).

#### § 761.366 Cleanup equipment.

(a) Use scrubbers and absorbent pads that are not dissolved by the solvents or cleaners used, and that do not shred, crumble, or leave visible fragments on the surface. Scrubbers and absorbent pads used to wash contaminated surfaces must not be reused. Scrubbers and absorbent pads for rinsing must not contain  $\geq 2$  ppm PCBs. Scrubbers and absorbent pads used in the second rinse of contaminated surfaces may be reused to wash contaminated surfaces.

(b) Capture and contain all solvents and cleaners for reuse, decontamination, or disposal. Clean organic solvents contain  $< 2$  ppm PCBs. Clean water contains  $< 3$  ppb PCBs.

#### § 761.369 Pre-cleaning the surface.

If visible PCB-containing liquid is present on the surface to be cleaned, thoroughly wipe or mop the entire surface with absorbent paper or cloth until no liquid is visible on the surface.

#### § 761.372 Specific requirements for relatively clean surfaces.

For surfaces that do not appear dusty or grimy before a spill, such as glass, automobile surfaces, newly-poured concrete, and desk tops, use the double wash/rinse procedures in this section.

(a) *First wash.* Cover the entire surface with organic solvent in which PCBs are soluble to at least 5 percent by weight. Contain and collect any runoff solvent for disposal. Scrub rough surfaces with a scrub brush or disposable scrubbing pad and solvent such that each 900 cm<sup>2</sup> (1 square foot) of the surface is always very wet for 1 minute. Wipe smooth surfaces with a solvent-soaked, disposable absorbent pad such that each 900 cm<sup>2</sup> (1 square foot) is wiped for 1 minute. Any surface  $< 1$  square foot shall also be wiped for 1 minute. Wipe, mop, and/or sorb the solvent onto absorbent material until no visible traces of the solvent remain.

(b) *First rinse.* Wet the surface with clean rinse solvent such that the entire surface is very wet for 1 minute. Drain and contain the solvent from the surface. Wipe the residual solvent off the drained surface using a clean, disposable absorbent pad until no liquid is visible on the surface.

(c) *Second wash.* Repeat the procedures in paragraph (a) of this section. The rinse solvent from the first rinse (paragraph (b) of this section) may be used.

(d) *Second rinse.* Repeat the procedures in paragraph (b) of this section.

#### § 761.375 Specific requirements for surfaces coated or covered with dust, dirt, grime, grease, or another absorbent material.

(a) *First wash.* Cover the entire surface with concentrated or industrial strength detergent or non-ionic surfactant solution. Contain and collect all cleaning solutions for proper disposal. Scrub rough surfaces with a scrub